

TECHNICAL DATASHEET

Hi-Tack Spray Bonding System Web Spray

Description & Uses

AlphaChem Web Spray is a high tack, multi purpose spray bonding system suitable for permanently bonding a wide variety of substrates, including wood, metals, rubber, fabric, most plastics, cardboard, polythene and concrete, as well as decorative laminates.

It is ideal for permanent bonds that require good initial bond strength. It provides good temperature resistance and if protected from contamination has an open time of several hours.

Always test a small sample of the materials first to ensure the suitability of the product for the application. For instance, some vinyls contain large amounts of plasticiser which, over time, can migrate and soften the bond. When in doubt, test first.



Directions

Surfaces should be clean, dry and free from grease, oil and dust. Excessive dust will impair performance. For best results the substrate and product should be bonded at temperatures between 15°C and 25°C.

- Attach a suitable spray nozzle, to the spray gun.
- Connect the hose to the canister and the spray gun to the hose and tighten the connections. If there are any leaks, tighten the connection at the source of the leak.
- Open the valve on the canister. The valve should remain open until the canister is used up. Use the locking nut on the gun after use. Turning off the valve will result in the adhesive drying in the hose and gun causing blockages.
- Hold the spray gun 10-20cm away at 90° to the surface and apply a uniform coat of adhesive, to both substrates, ensuring 80-100% coverage. Spray one surface vertically the other horizontally. Pay particular attention to the edges.
- When the adhesive is dry to the touch it is ready for the bond to be made.
- Porous substrates may require two applications
- Drying takes approximately 1 to 2 minutes depending on substrates, ambient temperature and humidity. Over spraying and pooling of the adhesive will increase the drying time and may cause the adhesive to show through the laminate.
- After spraying, remove the spray.
- It is important to remember that Web Spray is a contact adhesive and forms a bond by sticking to itself, so there must be sufficient adhesive **on both surfaces** for this to happen.
- Allow the adhesive to tack up and protect from contamination whilst this happens. The adhesive is ready to bond when it feels dry to the touch and does not transfer.
- Once the two surfaces have been brought together, and aggressive bond will be made. Spacers can be used to ensure the surfaces do not come into contact prematurely.

- Once the two surfaces are brought together, apply a uniform pressure over the work piece, starting in the middle and working outwards. Use blocks or a 3 inch roller and ensure the whole piece has been worked to ensure adequate contact of the adhesive.
- Pay particular attention to the edges. Please note that testing at this point by lifting the edge will weaken the bond. A nip roller will give the best results.
- Once assembled, the piece can be machined or trimmed as required.
- Full cure will take 24 hours.
- Keep the valve open and the hose attached to the canister until there is no more adhesive. If the hose is removed, clean through with solvent cleaner to prevent adhesive drying, which will cause the gun and hose to block. Turn the canister off before removing the hose.

Storage

Protect from extremes of temperature in a controlled environment between 15 and 35°C, and away from direct sunlight. Do not stand on a cold concrete floor. Low temperatures can result in irreparable separation of the adhesive. If the adhesive sprays like a jet, the canister is too cold. Warm to at least 10°C before using.

DO NOT ALLOW THE PRODUCT TO FREEZE

Shelf Life

Stored under the correct conditions, in original, unopened containers, the product will have a shelf life of 12 months.

Limitations

- Always test a small sample of the materials first to ensure the suitability of the product for the application. For instance, some vinyls contain large amounts of plasticiser which, over time, can migrate and soften the bond. When in doubt, test first.
- Do not use on flexible PVC or expanded polystyrene.
- It is the user's responsibility to ensure suitability for use.

Please read the label prior to use for essential health and safety information, further information can be found in the Safety Data sheet.

Technical Data

Solvent	Dichloromethane
Propellant	Hydrocarbon
Solids Content (approx.)	25-30%
Spray Pattern	Web
Colour	Clear
Coverage (17kg Canister)	128m ²
VOC	718g/l
Shear Adhesion Failure Temp	>100°
Fire Rating (spread of Flame)	Class 1
Wheelmark approved?	Yes

Further Information:

In the event of further queries or problems concerning the use of this product, please contact the address below, e-mail info@cromar.uk.com.

All products should be sold in accordance with the manufacturer's instructions. The manufacturer cannot be held responsible where conditions of use are beyond our control. Cromar Building Products Limited products' are available for sale in accordance with Cromar Building Products Limited standard conditions of sale, which is available upon request. Whilst any information contained herein is to the best of our knowledge true and accurate, no warranty is given or implied in connection with any recommendations, agents, or distributors, as the conditions of use and any labour involved are beyond our control. Our warranty is therefore limited to the quality of supplied product.